

Release for Production



SOFTWARE	
Change Notification (AE)	Scope: Global Production No.: AE_100_2019

Distribution	G	SL	PD	PDM	OM	QA	ENH Lorenz Laden- burger	RD	SE	PP	PM	ENH	EN	AE	RDL	RDE	RDA	Total
Sheet 1			X			X	X	X	X		X		X	X	X		X	10
Serial Sheet																		

Software for WLAN Socket Tray S169280-101-R1403

The Software S169280-101-R1403 for WLAN socket tray is released for production.

Bug fixes:

- PRR-12830: UDP communication was not used after start-up even if correct configured;
- PRR-12829: SRD communication was not possible to be configured via PC software;

Known limitations:

- The backup battery (lithium polymer accu) is not supported; if main battery is disconnected during startup the system can hang and a disconnection of the backup battery may be necessary;
- The voltage of the external power supply is not measured; a use of this power input is not possible as the software will switch-off the socket tray due to 'low battery' voltage;
- only Odin WLAN module is supported; for SRD communication an ODIN firmware ODIN-W26X-SW-7.0.0-090 or newer is necessary;

Software Date: 18.07.2019

Development Environment:
Atollic TruStudio 9.02

GCC Version 6.3.1

Target Hardware:	WLAN Socket Tray 4/8 943610PT, 9436xxPT
Link to Tag in SVN:	git@west012.atg.root:stm32/SocketTray.git , S169280_101_1403_ece0d1, ece0d1570a68a48b578cf7933f73fd76bc52ad32

For request to:			
AE	<input checked="" type="checkbox"/> - for consideration at new disposition	SE	<input checked="" type="checkbox"/> - for consideration at service benefits
	<input type="checkbox"/> - first consume old stock	SL	- information to all external agent representatives
	<input type="checkbox"/> - rework stock	EN	- creating material data in SAP
	<input checked="" type="checkbox"/> - for consideration at operation	PD	- ordering
<input checked="" type="checkbox"/> - information to all mechanics	- current orders		
RDS /	<input checked="" type="checkbox"/> - for consideration at new conception	RDL	- debut price
ENS /	<input checked="" type="checkbox"/> - for consideration at software duplication		- update test beds
ENH	<input type="checkbox"/> - update test beds		

	Editor:	Auditor:	Inspector:	Approval:	Order number:
Date	29.07.2019	22.07.2019	22.07.2019	22.7.19	
Name	RDH C. Titz	RDH A. Abele	RDL M. Opferkuch	RD/EN M. Kogel	